


WARNING HEAT GUN

Any piece of equipment can be dangerous if not operated properly. **YOU** are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

 **WARNING:** Electrical cords, cables, product cords, wire assemblies, and carrying cases made with PVC can expose you to chemicals including DEHP, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65warnings.ca.gov

- Never operate power equipment of any kind if you are tired or if you are under the influence of alcohol, drugs, medication or any substance that could affect your ability or judgment. Be alert! If you get tired while operating this equipment, take a break. Tiredness may result in loss of control.
- This 120-volt equipment may require a grounded outlet, do not modify plug.
- Always wear eye and dust protection.
- Don't Abuse Cord - Never carry tool by cord, or yank it to disconnect from receptacle.

IMPORTANT SAFETY RULES TO FOLLOW

1. Do not expose heat gun to rain or use in wet or damp locations.
2. Always disconnect heat gun when not in use.
3. Always wear proper clothing. Avoid jewelry or loose-fitting clothes. Wear safety glasses while operating heat gun.
4. Heat guns produce flameless heat at very high temperatures. Therefore, it is necessary to keep hands, face, hair, as well as clothing and other heat sensitive material out of the air stream.
5. Do not point the gun in the direction of anyone, any combustible materials such as trash, paint, paper, cloth, wood shavings, etc., as they might catch on fire. Do not operate around flammable or explosive materials.
6. Be sure switch is in the "OFF" position before plugging into outlet.
7. Never touch heat nozzle until it has cooled.
8. Never use if cord is damaged or frayed. Avoid pulling on cord or shooting with heat gun. Electrical shock can occur.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment, **DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!! FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH**