WARNING AWP 30S PLATFORM LIFT "MEWP"

Any piece of equipment can be dangerous if not operated properly. <u>YOU</u> are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, <u>DO NOT USE THIS</u>

<u>EQUIPMENT!!!</u> This Page Contains Basic Guidelines & Safety Warnings For This Lift. But It Is Not A Substitute For The Operators Manual. <u>READ THE</u>

<u>OPERATORS MANUAL!</u>

Due to job site or employer rules. Each occupant of the platform may be required to wear personal fall protection equipment. (A Safety Harness with Lanyard attached to the Lanyard Anchorage)

TIP OVER HAZARD, this lift is for use on level compacted surfaces only!

Warning: Misuse, operating when not level and overloading the platform will cause this Lift to tip over. The Equipment Protection Plan does not cover damage from tip over

OPERATING INSTRUCTIONS

The *Operator's Manual* is located in the red plastic box in the operator's platform.

Before you operate this lift, read, understand and obey all the safety rules and operating instructions in the Operator's Manual

Always perform a pre-operation inspection and function test prior to use for every shift, as outlined in the Operator's Manual.

IMPORTANT SAFETY RULES TO FOLLOW

- 1. Do not raise platform unless base is level, all four outriggers are properly installed with leveling jacks firmly contacting the floor.
- 2. Do not adjust or remove outriggers while platform is occupied or raised.
- 3. Do not move machine while the platform is raised.
- 4. Do not place or attach overhanging loads to any part of this machine.
- 5. Do not place or attach ladders in platform or against any part of this lift.
- 6. Do not use this machine to lift material or equipment.
- 7. Do not raise platform in strong or gusty winds.
- 8. Maximum platform capacity is 350lbs. Maximum allowable side force ANSI / CSA 50lbs / 222 N. Maximum occupancy is one person.
- 9. Do not sit, stand, or climb on platform guardrails. Both feet must always be on the platform!
- 10. Do not exit platform while raised.
- 11. This machine is not electrically insulated and will not provide protection from contact with electrical current.

Voltage

- 12. Maintain a safe distance from any power lines.
- 13. Keep all personnel away from machine when operating, raising, or lowering.
- 14. Do not leave machine unattended at any time.
- 15. Batteries contain acid. Always wear protective clothing and eyewear when working with batteries.
- 16. Do not expose battery or machine to water and/or rain.
- 17. Battery Needs To Be Charged Daily. Check Battery Water Before Charging
- 18. Battery must remain in an upright position at all times.

Warning metal conducts electricity. Do Not use this lift where it may come into contact with power lines or other electric circuts. Failure to comply to this warning will result in serious personal injury or death. For appropriate distances from High Voltage lines see chart below.

Maintain safe distances away from electrical power lines and apparatus in accordance with applicable governmental regulations and the following chart

voltage	Millillian Sale	
Approa	schable Distance	
Phase to Phase	Feet	Meters
0 to 300V	Avc	oid Contact
300V to 50KV	10	3.1
50KV to 200KV	15	4.6
200KV to 350KV	20	6.1
350KV to 500KV	25	7.6
500KV to 750KV	35	10.7
750KV to 1000KV	45	13.7

Minimum Safe

Allow for mast movement and electrical line sway or sag, and be aware of strong or gusty winds. Do not use the machine as a ground for welding.

WARNING: This product can expose you to sulfuric acid from batteries which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment, <u>DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!</u> FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH

To be filled out by the Yard Person doing the customer hook up or Delivery Driver delivering the lift. Upon completion attach it to the original contract.

PRE-RENTAL SAFETY CHECK LIST

ATS # DATE CONTRACT#
A-1 OPERATOR'S & SAFETY MANUALS
A-2 DECALS & PLACARDS
A-3 DAMAGED, LOOSE or MISSING PARTS
A-4 DEXRON HYDRAULIC OIL LEVEL & LEAKS
A-5 MANUAL LOWERING OPERATION
A-6 BATTERY & CHARGER
A-7 COLUMNS
A-8 SEQUENCING CABLES
A-9 CHECK INTERLOCK SYSTEM ON OUTRIGGERS
A-10 TEST THE POWER & FUNCTION CONTROLS
A-11 INSPECT THE LIFTING CHAINS & IDLER WHEELS
INSPECTED BY (print)
INSPECTED BY (signature)

To be filled out by the Yard Person doing the customer hook up or Delivery Driver delivering the lift. Upon completion attach it to the original contract.

CONTRACT #	EMPLOYEE NAME:
QUALIFIED (OPERATOR ACKNOWLEDGMENT
1. Operator was shown the Operator	or and ANSI Manuals.
OPERATORS INITIALS	
shift. These procedures are detailed	e-Operation Inspection and Function Test" must be performed before each in the Operator's Manual. If any problems or malfunctions are found Do bely call A Tool Shed so we can repair or replace the lift.
OPERATORS INITIALS	
	or will inspect the jobsite for hazards, including but not limited to: operation les, debris, obstructions (floor or overhead), high voltage conductors, wind,
OPERATORS INITIALS	
4. Operator Acknowledges that the	y are Qualified to operate this lift.
OPERATORS INITIALS	
• •	erate the equipment, and shall do so in accordance with the full provisions rovided. Only lessee's trained operators are authorized to operate the se this equipment.
OPERATORS INITIALS	
Customer Acknowledges the Pair EXCELLENT GOO	
COMMENTS	
OPERATORS SIGNATURE:	DATE:
PRINTED NAME:	