


WARNING HAND POST DRIVER

Any piece of equipment can be dangerous if not operated properly. **YOU** are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced, or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

⚠ WARNING: This product can expose you to chemicals including Chromium from steel products which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

DANGER: This equipment has multiple pinch points that can cause dismemberment or death. Keep hands, feet and all other body parts clear at all times.

Wear safety glasses, steel toed safety boots, and gloves while using this tool.



This is a simple tool, that is used to manually drive many different types of fence posts. From “T” posts, “U” posts, or any other type – as long as it fits inside the tube of the post driver.

There are 3 easy steps to follow to successfully drive a fence post with a manual post driver:

Step 1: Slide post inside of the post driver and raise both to a vertical position.

Step 2: With a good grip & comfortable stance, raise the post driver several inches off the top of the post and bring it down onto the post with force.

Step 3: Repeat, until post has been driven into the ground to the desired depth.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment, **DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!! FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH**