

WARNING SAFETY TOILET JACK

Any piece of equipment can be dangerous if not operated properly. **YOU** are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. **IF** any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

IMPORTANT SAFETY RULES TO FOLLOW

DANGER: THIS EQUIPMENT HAS & CREATES MULTIPLE PINCH POINTS THAT CAN CAUSE DISMEMBERMENT OR DEATH! KEEP HANDS, FEET AND ALL OTHER BODY PARTS CLEAR AT ALL TIMES. Maximum Capacity 175 pounds.

Use only on smooth, hard, level surfaces.

Do Not place hands or fingers between angle Iron and lifting arms when holding or lowering a load.

Instructions for Floor Mount Toilets



STEP 1
Close water valve, flush toilet, and disconnect supply line. Remove toilet bolt nuts and washers. Roll jack under toilet bowl.



STEP 2
Use jack lever to raise toilet above old seal and flange bolts. Toilet can be rolled and safely held in desired area. Drain can be cleaned and cleared, sub floor and flange can be repaired, new floor can be installed, etc.



STEP 3
When ready to install same toilet or a new toilet, place new seal on cleaned floor flange, centered between flange bolts or on cleaned toilet horn.

Instructions for Wall Mount Toilets



STEP 1
Close water supply valve. Remove supply line. Roll jack under toilet bowl. Raise the lifting arms to support the weight of toilet.



STEP 2
Remove both left and right side nuts and washers.



STEP 3
Back toilet away from wall and mounting bolts. Toilet can be rolled to desired area. With toilet safely held, the drain can be cleaned and cleared, old wax seal can be changed, etc.

* Remember gently open release. Let toilet descend very slowly.



STEP 4
Roll toilet in over flange bolts. Use release to very slowly lower toilet base about 2 inches above bolts. Place left and right alignment tubes through toilet base slots and over flange bolts.



STEP 4
To install the same toilet or new toilet, place new seal in proper position and simply roll toilet in to receive mounting bolts. Seal is aligned and toilet is held for you.



STEP 5
Slowly lower toilet to the floor. Bolts are installed for you. Toilet is aligned. Remove jack. Remove alignment tubes. Install bolt washers and nuts. Tighten down toilet. Connect supply line. Open water valve.



STEP 5
Install washers and nuts, snug by hand, release and remove jack. Tighten nuts to secure the seal and toilet to wall.

⚠ WARNING: This product can expose you to chemicals including naphthalene and benzene from petroleum products which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment,

DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!
FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH